



## **SPEED DIAL**

You can call emergency, frequently dialed, or long distance numbers just by dialing one or two number. You have the choice of selecting either a short list of eight (8) numbers or a longer list of thirty (30) numbers.

### **To Enter Or Change Your Speed Dialing List:**

- Lift the receiver and listen for dial tone
- If you have an (8) number Speed Dial, dial \*74 on a touchtone phone
- If you have a (30) number Speed Dial, dial \*75 on a touch tone phone
- Dial one of the Speed Dial codes
  1. (8) number – dial any number from 2-9
  2. (30) number – dial any number 20-49
- Then immediately dial the number you wish to enter under the selected Speed Dial number. Long distance entries require (1) and the area code.
- Press the # button
- Listen for the confirmation beeps which indicate your number has been entered